INSTALLATION INSTRUCTIONS

READ IMPORTANT SAFETY TIPS BEFORE PROCEEDING WITH INSTALLATION


Turn fixture off! (Place wall switch in off position, if fixture has built-in switch or chain pull, switch or pull chain so fixture is off.)




Next - go to the main fuse box. If your fuse box has an ON/OFF switch, Screw-in type fuses - unscrew the fuse simply place main power switch in or fuses that control the power to the OFF position.




fixture or room you are working in.




THREAD fixture mounting screws (provided) into outer cross bar. ATTACH cross bar to outlet box with outlet box screws (not provided)




CONNECT THE WIRES. NOTE: Attach black fixture wire to black supply wire, white fixture wire to white supply wire. Do not mix them up. Use wire connectors (not provided), NEVER CONNECT GROUND WIRE TO BLACK OR WHITE POWER SUPPLY WIRES.



POSITION THE FIXTURE HOUSING over the fixture mounting screws and secure in place with the thumb nuts provided.




ATTACH FIXTURE CAGE TO FIXTURE HOUSING. Squeeze cage as shown. Position holes on side of cage over corresponding pins on underside of housing. Release cage pins will snap into position.



textured side out, then drop in side panels.



HOLD LEFT SIDE PANEL AGAINST SIDE



NOTE: Fixture MUST be caulked with an acrylic caulk where fixture housing meets mounting surface. This provides a water tight seal when fixture is installed.

OPTIONAL PHOTO SENSOR: If this fixture OF CAGE. Rotate free end of cage up to the has a photo sensor switch, do not apply BEFORE SNAPPING HOUSING SHUT, housing and snap into place. Screw bulb into excessive force to leads connected to photo install front and rear plastic panels first, socket. Be sure to use bulb with wattage no sensor. Photo sensor must remain in clear window for proper operation

This fixture may have an integral photo sensor that turns the fixture off during the day and on at night. The photo sensor is not adjustable. The fixture could possibly cycle on and off due to light reflected from nearby surfaces into the photo sensor. If cycling occurs, remove the photo sensor nut and install the swivel hood and base.

greater than specified for this fixture.



The hood and base are adjustable. The hood can be rotated and the base can be cut along the dotted line to reduce overall length. Check operation before cutting the base.

INSTALLATION INSTRUCTIONS


Turn fixture off! (Place wall switch in off position, if fixture has built-in switch or chain pull, switch or pull chain so fixture is off.)




Next - go to the main fuse box. If your fuse box has an ON/OFF switch, OFF position.




Screw-in type fuses - unscrew the fuse simply place main power switch in or fuses that control the power to the fixture or room you are working in.




THREAD fixture mounting screws (provided) into outer cross bar. ATTACH cross bar to outlet box with outlet box screws (not provided)




CONNECT THE WIRES. NOTE: Attach black fixture wire to black supply wire, white fixture wire to white supply wire. Do not mix them up. Use wire connectors (not provided). NEVER CONNECT GROUND WIRE TO BLACK OR WHITE POWER SUPPLY WIRES.



POSITION THE FIXTURE HOUSING over the fixture mounting screws and secure in place with the thumb nuts provided.




ATTACH FIXTURE CAGE TO FIXTURE HOUSING. Squeeze cage as shown. Position holes on side of cage over corresponding pins on underside of housing. Release cage pins will snap into position



install front and rear plastic panels first, socket. Be sure to use bulb with wattage no sensor. Photo sensor must remain in clear textured side out, then drop in side panels.



HOLD LEFT SIDE PANEL AGAINST SIDE OF CAGE. Rotate free end of cage up to the has a photo sensor switch, do not apply BEFORE SNAPPING HOUSING SHUT, housing and snap into place. Screw bulb into excessive force to leads connected to photo



NOTE: Fixture MUST be caulked with an acrylic caulk where fixture housing meets mounting surface. This provides a water tight seal when fixture is installed

OPTIONAL PHOTO SENSOR: If this fixture window for proper operation

This fixture may have an integral photo sensor that turns the fixture off during the day and on at night. The photo sensor is not adjustable. The fixture could possibly cycle on and off due to light reflected from nearby surfaces into the photo sensor. If cycling occurs, remove the photo sensor nut and install the swivel hood and base.

greater than specified for this fixture.



The hood and base are adjustable. The hood can be rotated and the base can be cut along the dotted line to reduce overall length. Check operation before cutting the base.



Clean only with mild soap and water. Avoid spraying with cleansers, insecticides, and pesticides that are petroleum based hydrocarbon products. These will degrade luminaire. IS7033 Rev. D